



10/550445

図 1




10/550445

図 2




10/550445

図 3




10/550445

図 4



10/550445


図 5



- |    |           |    |                                  |
|----|-----------|----|----------------------------------|
| 12 | ワンブッシュボタン | 12 | WIRELESS COMMUNICATION CIRCUIT   |
| 23 | 開閉検知スイッチ  | 23 | OPENING/CLOSING DETECTION SWITCH |
| 21 | 回路制御部     | 21 | CIRCUIT CONTROL SECTION          |
| 24 | 受話器       | 24 | TELEPHONE RECEIVER               |
| 25 | 送話器       | 25 | TELEPHONE MICROPHONE             |
| 5  | キー操作部     | 5  | KEY OPERATION SECTION            |
| 5a | 通話キー      | 5a | TALK KEY                         |
|    | ダイヤルキー    |    | DIAL KEY                         |
|    | 通話終了キー    |    | TALK COMPLETION KEY              |
|    | その他の操作キー  |    | OTHER OPERATION KEYS             |

10/550445

図 6



11 INCOMING CALL  
 12 HOUSING OPENING/CLOSING DETECTION  
 13 OPENING  
 14 CLOSING  
 15 TALK KEY LED OFF  
 16 ONE-PUSH BUTTON LED ON  
 17 HOUSING OPENING/CLOSING DETECTION  
 18 OPENING  
 19 CLOSING  
 20 ONE-PUSH BUTTON LED OFF  
 21 TALK OVER PHONE  
 22 TALK KEY LED ON  
 23 ONE-PUSH BUTTON LED OFF  
 24 HOUSING OPENING/CLOSING DETECTION  
 25 OPENING  
 26 CLOSING  
 27 TALK KEY  
 28 TALK KEY LED OFF

10/550445

図 7

着信時のLED状態

	開	閉	閉 → 開
ワンプッシュボタン LED	OFF	ON	OFF
通話キー LED	ON	OFF	OFF
着信 LED	ON	ON	OFF

着信時のLED状態

ワンプッシュボタンLED

通話キーLED

着信LED

開

閉

閉 → 開

LED STATE AT THE TIME OF INCOMING CALL

ONE-PUSH BUTTON LED


TALK KEY LED

INCOMING CALL LED

OPENING

CLOSING

CLOSING → OPENING



S22 HOUSING OPENING/CLOSING DETECTION  
開 OPENING  
閉 CLOSING  
S23 ONE-PUSH BUTTON LED OFF  
S24 TALK KEY LED ON  
S25 CAR-MOUNTED ADAPTER CONNECTED  
(EXTERNAL IF INSERTED)  
有 YES  
無 NO  
S26 HANDS-FREE SWITCH OF CAR-MOUNTED AD  
S29 EARPHONE INSERTED  
有 YES  
無 NO  
S30 EARPHONE SWITCH  
S31 TALK KEY  
S27 TALK KEY LED OFF  
S28 TALK OVER PHONE  
S32 ONE-PUSH BUTTON LED ON  
S33 TALK KEY LED OFF  
S34 CAR-MOUNTED ADAPTER CONNECTED  
(EXTERNAL IF INSERTED)  
有 YES  
無 NO  
S35 HANDS-FREE SWITCH OF CAR-MOUNTED AD  
S37 EARPHONE INSERTED  
有 YES  
無 NO  
S38 EARPHONE SWITCH  
S39 HOUSING OPENING/CLOSING DETECTION  
開 OPENING  
閉 CLOSING  
S36 ONE-PUSH BUTTON LED OFF